

PLCS Encapsulation Parts List

Description	Part #	Sealant liters required per kit
LP Bell Joint		
4"	01-104	included
6"	01-106	included
8"	01-108	included
12"	01-112	included
16"	01-116	included
20"	01-120	included
24"	01-124	10.0
30"	01-130	12.5
36"	01-136	17.5
48"	01-148	22.5
Flex-Kit (for keyhole or core drilled excavation)		Small hole bell joint
3"	02-303	included
4"	02-304	included
6"	02-306	included
8"	02-308	included
10"	02-310	included
12"	02-312	included
Flex-Kit for Undersized Hub (less than sizes below)		
4" (diameter 8.35" circumference 26.25")	02-304-U	included
6" (diameter 10.5" circumference 33.125")	02-306-U	included
8" (diameter 13" circumference 40.875")	02-308-U	included
10" (diameter 15.07" circumference 47.375")	02-310-U	included
Sealant		
15 Liters	01-615	
10 Liters	01-610	
7.5 Liters	01-607	
5 Liters	01-605	
3 Liters	01-603	
2.5 Liters	01-602	
LP Style 38 Coupling		
3"	01-203	5
4"	01-204	7.5
6"	01-206	10
8"	01-208	15
10"	01-210	20
12"	01-212	25
16"	01-216	30
20"	01-220	45
24"	01-224	55
30"	01-230	65
36"	01-236	80

PLCS, LLC.

102 Gaither Drive, Unit 1, Mount Laurel, NJ 08054, USA

phone: (856) 722-1333 fax: (856) 273-9723 e-mail: info@plcsusa.com web www.plcsusa.com

Description	Part #	Sealant liters required per kit
LP Style 40 Coupling		
3"	01-503	10
4"	01-504	15
6"	01-506	20
8"	01-508	25
10"	01-510	35
12"	01-512	40
16"	01-516	60
20"	01-520	75
24"	01-524	90
LP Split Sleeve		
4"	01-304	15
6"	01-306	17.5
8"	01-308	27.5
10"	01-310	35
12"	01-312	40
16"	01-316	50
LP Service Sleeve		
4"	01-404	17.5
6"	01-406	20
8"	01-408	30
10"	01-410	37.5
12"	01-412	42.5
16"	01-416	52.5
LP Style 80 Split Sleeve		
4"	01-324	15.0
6"	01-326	20.0
8"	01-328	25.0
LP Style 80 Service Sleeve		
4"	01-424	15
6"	01-426	20
8"	01-428	25
LP Mechanical		
3"	01-803	5
4"	01-804	5
6"	01-806	7.5
8"	01-808	10
10"	01-810	12.5
12"	01-812	17.5
16"	01-816	22.5
20"	01-820	27.5
24"	01-824	37.5

PLCS, LLC.

102 Gaither Drive, Unit 1, Mount Laurel, NJ 08054, USA

phone: (856) 722-1333 fax: (856) 273-9723 e-mail: info@plcsusa.com web www.plcsusa.com

Description	Part #	Sealant liters required per kit
LP End Plug		
4"	02-404	5
6"	02-406	5
8"	02-408	7.5
10"	02-410	10
12"	02-412	10
16"	02-416	15
20"	02-420	20
24"	02-424	25
LP Innertite		
4"	02-504	15
6"	02-506	15
8"	02-508	17.5
12"	02-512	25
LP Stainless Steel Full Circle Clamps up to 15" long		
4"	02-104	12.5
6"	02-106	17.5
8"	02-108	22.5
10"	02-110	27.5
12"	02-112	32.5
Dresser Style 31 End Caps		
4"	01-704	10.0
6"	01-706	15.0
8"	01-708	20.0
MP Bell Joint		
4"	04-104	2.5
6"	04-106	2.5
8"	04-108	3
10"	04-110	5
12"	04-112	5
16"	04-116	7.5
20"	04-120	10
24"	04-124	15
30"	04-130	17.5
36"	04-136	20
42"	04-142	35 (20 psi max)
MP Style 38 Coupling		
3"	04-203	6.5
4"	04-204	7.5
6"	04-206	12.5
8"	04-208	15
10"	04-210	20
12"	04-212	30
16"	04-216	35
20"	04-220	50

PLCS, LLC.

102 Gaither Drive, Unit 1, Mount Laurel, NJ 08054, USA

phone: (856) 722-1333 fax: (856) 273-9723 e-mail: info@plcsusa.com web www.plcsusa.com

Description	Part #	Sealant liters required per kit
MP Style 40 Coupling		
4"	04-504	20
6"	04-506	27.5
8"	04-508	35
10"	04-510	45
12"	04-512	52.5
MP Inertite		
4"	04-704	15
6"	04-706	20
8"	04-708	25
12"	04-712	35
16" (Requires a Re-Usable Metal Shroud)	04-716F	45
16" Metal Shroud	04-746	
20" (Requires a Re-Usable Metal Shroud)	04-720F	60
20" Metal Shroud	04-750	
24" (Requires a Re-Usable Metal Shroud)	04-724F	75
24" Metal Shroud	04-754	
30" (Requires a Re-Usable Metal Shroud)	04-730F	90
30" Metal Shroud	04-760	
36" (Requires a Re-Usable Metal Shroud)	04-736F	105
36" Metal Shroud	04-766	
MP Mechanical		
4"	04-804	7.5
6"	04-806	10
8"	04-808	12.5
10"	04-810	15
12"	04-812	17.5
16"	04-816	25
20"	04-820	30
24" (Requires a Re-Usable Metal Shroud)	04-824	
NORMAC/Style 90 Coupling		
(end nuts must be tightened to stop leak first)		
3/4" - 1 1/4"	01-750	included
1 1/2" - 2"	01-752	included

PLCS, LLC.

102 Gaither Drive, Unit 1, Mount Laurel, NJ 08054, USA

phone: (856) 722-1333 fax: (856) 273-9723 e-mail: info@plcsusa.com web www.plcsusa.com