

# Mudtight GOLD

## Instructions 6" IPS and Larger

This product is patented.

**1**

Eyebolt Washer  
Nose  
Cartridge  
Grippers  
Tail

Unscrew the rear eye. Place the towing head on it's tail and unscrew the eyebolt. Lift off the nose and cartridge.

**2**

Silicone based spray or grease

Squeeze the cartridge to make sure the seals expand easily. Lubricate the seals if necessary. Silicone spray or silicone based grease (e.g. Molykote) is preferred.

**3**

Place the cartridge back on top of the grippers with the required size downward. Make sure the pipe is cut squarely and is clean.

**4**

Re-assemble making sure

- The cartridge is the required way around.
- The sealing O Ring is in its recess in the nose.
- The tail is screwed up to just touch the grippers.
- The rear eye is tight and not touching the tail.

**5**

Look inside and make sure the sealing O ring is not expanded. Slide fully into the pipe and tighten. The towing head is now ready for use.

**6**

To remove the towing head unscrew the eyebolt. If the eyebolt comes out of the nose then gently tap it back in to release the grippers. The towing head should now slide off. If the towing head is stuck then try – Tapping the PE pipe behind the head to release the grippers. Waiting 15 minutes for the pipe to contract away from the sleeve. Do not attempt to remove the towing head by HAMMERING off of the pipe.

After use dismantle fully, clean, lubricate and re-assemble.